

The operation manual of the Euro calculator

1. Important notice!

Please remove the insulating plastic sheet from the backside of the Euro calculator before use.

2. Switching on and nullifying the Euro calculator

Press "ON/C" to switch on and to nullify the display.

3. Checking the exchange rate

Press "KURSS" and check if the upper line bears the number "1.00" and the bottom line "15.6466". In case different numbers from the ones mentioned above are displayed, please see section 12 of this operation manual.

4. Converting Estonian kroons into Euros

Press "EEK" and insert the desired number. The Euro calculator will automatically display the corresponding number in Euros on the upper line.

5. Converting Euros into Estonian kroons

Press "EURO" and insert the desired number. The Euro calculator will automatically display the corresponding number in Estonian kroons on the upper line.

6. Calculating function

Press "CAL" and check if the word "CAL" appears on the upper line and "0" on the bottom line. Now the Euro calculator functions as a simple calculator with options to add, subtract, multiply and divide.

7. Moving from calculating function to converting into Estonian kroons

In case you wish to convert the final result of the calculations which appears on the bottom line into Estonian kroons, please press "EEK". The Euro calculator will automatically display the corresponding number in Estonian kroons on the bottom line.

8. Moving from calculating function to converting into Euros

In case you wish to convert the final result of the calculations which appears on the bottom line into Euros, please press "EURO". The Euro calculator will automatically display the corresponding number in Euros on the bottom line.

9. Extra explanation

One can conveniently distinct which line bears the sum in Euros by examining the marks on the left side of the display on both lines. The sum on the line that has the Euro mark (€) is always displayed in Euros.

10. Switching off the Euro calculator

The Euro calculator will automatically switch off if it has not been used for eight minutes.

11. Changing the battery

If when pressing "ON/C" nothing appears on the display then most probably the battery is dead. In such a case open the small hatch on the backside of the calculator using a screwdriver and then change the battery. The batteries approved by the producer are AG10 and L1131.

12. Warranty

In case there are malfunctions with the Euro calculator, please visit <http://euro.eesti.ee> or dial +372 800 3330 for extra information. The Ministry of Finance of Estonia assures to replace all Euro calculators that do not work because of production faults until 15. September 2012. The warranty does not cover changing the batteries.